








# RevoFit®

SKU	Product	Description	Picture	Available
RF-200-07-01	RevoFit® Lamination Kit	This single RevoFit Lamination Kit allows you to build in user-controlled adjustability anywhere on a socket.		10/1/2021
RF-200-07-10	RevoFit® Lamination Fabricators 10-Pack	Large practices, regular users and central fabricators save money and always have a kit ready to use by ordering the Fabricators 10-Pack.	<b>Contents:</b> <ul style="list-style-type: none"> <li>○ 10 Lamination Collars</li> <li>○ 10 Lamination Tubes - 1.5m</li> <li>○ 10 Click® Reels</li> <li>○ 25m Indicator Lace</li> <li>○ 5 Lace Feeders</li> <li>○ 3 Click® Reel Tools</li> <li>○ 3 Click® Reel Lock Plugs</li> </ul>	10/1/2021
RF-201-07-01	RevoFit® Diagnostic Kit	This single RevoFit Diagnostic Kit lets you adjust even earlier in socket development. Used for validating design and function of a RevoFit system on a patient during the diagnostic socket stage only.		10/1/2021

RP-000-07	Click® Reel and Lace Kit	Replacement Click Reel and 2m of Lace for RevoFit, RevoSurface and all RevoLock Kits.		10/1/2021
RP-001	Indicator Lace Kit	Replacement Indicator Lace (2m) for RevoFit, RevoSurface and all RevoLock Kits.		10/1/2021
RP-102	Surface Collar + Surface Shim	Replacement Surface Collar and Shim for RevoFit Diagnostic & RevoSurface Kits only.		10/1/2021
RP-200	Lamination Collar	Replacement Lamination Collar for RevoFit and all RevoLock Kits.		10/1/2021
RP-201	Lamination Tube - 1.5m	Replacement Lamination Tube (1.5m) for RevoFit and all RevoLock Kits.		10/1/2021
BL-001	Indicator Lace - 25m Spool	Bulk Indicator Lace (25m spool) for RevoFit, RevoSurface and all RevoLock Kits.		10/1/2021

BL-201	Lamination Tube - 18m Spool	Bulk Lamination Tube (18m spool) for RevoFit and RevoLock Kits.		10/1/2021
--------	-----------------------------	---	---	-----------